S-BUS protocol

Note- Much of this first page is from mbed, but it was written for the original s.bus using the "FASST MULT" mode. Here's the original page linkhttp://mbed.org/users/Digixx/notebook/futaba-s-bus-controlled-by-mbed/

The protocol is 25 Byte long and is send every 14ms (analog mode) or 7ms (highspeed mode). One Byte = 1 startbit + 8 databit + 1 paritybit + 2 stopbit (8E2), baudrate = 100'000 bit/s, so one bit takes 10 microseconds.

The highest bit is send first, so data "00000000001" = 1024"

The logic is inverted out of the receiver.

```
[startbyte] [data1] [data2] .... [data22] [flags][endbyte]
startbyte = 11110000b (0xF0)
data 1-22 = [ch1, 11bit][ch2, 11bit] .... [ch16, 11bit] (ch# = 0 bis 2047)
channel 1 uses 8 bits from data1 and 3 bits from data2
channel 2 uses last 5 bits from data2 and 6 bits from data3
etc.
flags = bit7 = ch17 = digital channel (0x80)
bit6 = ch18 = digital channel (0x40)
bit5 = Frame lost, equivalent red LED on receiver (0x20)
bit4 = failsafe activated (0x10)
bit3 = n/a
bit2 = n/a
bit1 = n/a
bit0 = n/a
```

endbyte = 00000000b (Prior to the s.bus2 capable receivers, and the R7003SB)

The above info was decoded from the earlier s.bus receivers, before the R7008SB came out. The new receiver is sold with 18MZ and 14SG radios, and offers telemetry, as well as the ability to output PWM, s.bus, and s.bus2 at the same time. Unfortunately, it was immediately noted that none of the FC boards which previously supported s.bus worked with the new R7008SB.

Fortunately, not much changed in the protocol for the R7008SB. The original protocol above seems to be the same in the new R7008SB, with the exception of the endbyte. In the previous version, for example with the R6203SB receiver, the endbyte data was always 00000000. Now, the endbyte data seems to vary some.

"FASSTest 18CH" mode generates s.bus frames every 15ms. It allows 16 channels, plus two digital (on/off) channels, and all telemetry sensors to be used. Using "FASSTest 18CH" with the R7008SB, I've only captured the following 4 variations of endbyte data. I've tried everything I can think of to generate something different, but these are the only ones I can create. They appear in rotation in the order shown, which appears to form a two bit 0-3 counter (remembering that the high order bit is to the right).

00100000 00101000 00100100 00101100

"FASSTest 12CH" mode generates frames every 6.3ms. This only allows 10 channels, plus 2 digital (on/off) channels, and it only allows RX and Ext bat voltages for telemetry. For the "FASSTest 12CH" mode using the R7008SB, the protocol is the same, except the endbyte is fixed at 00010000. This would actually make an easy fix from the original s.bus code if you only wanted to use the FASSTest 12CH mode.

There's another brand new (about April 2013) receiver called the R7003SB. I assumed it wouldn't work with the old FC code either, but I was wrong:-) I've just captured the output, and it looks just like the older R6203SB. I just tested in on an OP board with the original s.bus code, and it works perfectly. This is very good news! The only reason not to use the R7003SB is in the case where you need more than 1-2 PWM channels directly from the receiver. Also, those channels have to be low, so if need to use a high channel number because your FC won't let you reassign (most will) then you would need the R7008SB.

Rusty

18MZ to R6203SB- "FASST MULTI" (all channels null)

(as captured)

```
(inverted before FC input)
(inverted before FC input and grouped in 12 bit bytes)
011110000011 (Start byte)
00000000011 (data 1)
000100000111 CH1
000000111111 CH2
000000000011 CH3
011000000011 CH4
000010000111 CH5
000000010111 CH6
00000000011
001000000111 CH7
000001000111 CH8
00000001111
00000000011 CH9
000100000111 CH10
000000100111 CH11
00000000011
010000000111 CH12
000010000111 CH13
000000010111 CH14
00000000011
001000000111 CH15
000001000111 CH16
00000001111 (data 22)
00000000011 (flags byte) DCH1, DCH2, Frame lost, failsafe activated, rest are NA
```

00000000011 (11 added by dead space between frames)

18MZ to R6203SB -"FASST MULTI" (all channels null except ch1= 100%)

(inverted before FC input, difference from previous "all null" capture in red)

(inverted before FC input, and grouped in 12 bit bytes) 011110000011 (Start byte) 011111001011 (data 1) 001100000011 CH1 000000111111 CH2 000000000011 CH3 011000000011 CH4 000010000111 CH5 000000010111 CH6 00000000011 001000000111 CH7 000001000111 CH8 00000001111 00000000011 CH9 000100000111 CH10 000000100111 CH11 00000000011 010000000111 CH12 000010000111 CH13 000000010111 CH14 00000000011 001000000111 CH15 000001000111 CH16 00000001111 (data 22) 00000000011 (flags byte) DCH1, DCH2, Frame lost, failsafe activated, rest are NA

000000000 11 (11 added by dead space between frames)

18MZ to R7008SB - "FASSTest 18CH" (all channels null)

000100100011

```
(as captured)
(inverted as seen by FC)
(inverted as seen by FC)
011110000011 (Start byte)
00000000011 (data 1)
000100000111 CH1
000000110011 CH2
0111111111011 CH3
001000000111 CH4
000010000111 CH5
000000010111 CH6
00000000011
001000000111 CH7
000001000111 CH8
00000001111
00000000011 CH9
000100000111 CH10
000000100111 CH11
00000000011
010000000111 CH12
000010000111 CH13
000000010111 CH14
00000000011
001000000111 CH15
000001000111 CH16
00000001111 (data 22)
00000000011 (flags byte) DCH1, DCH2, Frame lost, failsafe activated, rest are NA
(last byte cycles through these 4 versions in this order- added by dead space between frames)
000100000111
000101000011
```

18MZ to R7008SB - "FASSTest 12CH" (all channels null)

(as captured)

(inverted as seen by FC)

```
(inverted as seen by FC)
011110000011 (Start byte)
00000000011 (data 1)
000100000111 CH1
000000100111 CH2
000000000011 CH3
011000000011 CH4
000010000111 CH5
000000010111 CH6
00000000011
001000000111 CH7
000001000111 CH8
00000001111
00000000011 CH9
000100000111 CH10
000000100111 CH11
00000000011
010000000111 CH12
000010000111 CH13-NA
000000010111 CH14-NA
00000000011
001000000111 CH15-NA
000001000111 CH16-NA
00000001111 (data 22)
00000000011 (flags byte) DCH1, DCH2, Frame lost, failsafe activated, rest are NA
000010000111 (endbyte)
```

```
18MZ to R7003SB - "FASSTest 12CH" (all channels null) 18MZ to R7003SB - "FASSTest 18CH" (all channels null) (both the same)
```

(as captured)

(inverted as seen by FC)

```
(inverted as seen by FC)
011110000011 (start byte)
000000000011 (data 1)
000100000111 CH1
000000100111 CH2
000000000011 CH3
011000000011 CH4
000011111111 CH5
010010110011 CH6
00000000011
001000000111 CH7
000001000111 CH8
00000001111
00000000011 CH9
000100000111 CH10
000000100111 CH11
00000000011
010000000111 CH12
000010000111 CH13-NA
000000010111 CH14-NA
00000000011
001000000111 CH15-NA
000001000111 CH16-NA
00000001111 (data 22)
00100000111 (flags byte) DCH1, DCH2, Frame lost, failsafe activated, rest are NA
00000000011 (end byte)
```